



10.CAUTION

- When the temperature is too high, HI will be displayed in the temperature area to express the room temperature over the display range. When the temperature is too low, LO will be displayed in the temperature area to express the room temperature below the display range.
- Two AA batteries can be used for one year. When the battery voltage symbol flashes, it means the batteries need to be changed. Please change the batteries sooner.
- Within the 20 minutes after remove the batteries, time and week will keep running. Please change the batteries in this period.
- There is preservative on the LCD when out of the factory, users can remove it or not.
- If you need to remove the preservative, just pull it from the corner and no need to open the thermostat.
- Don't force to install. When it is hard to connect the pin, move the display panel slightly. After the pin aimed at the port, press the thermostat hard.
- It is precision electronic products. Don't knock or fall it.
- Don't let the water, mud into the thermostat.

11.SPECIFICATIONS

Specifications


the display range of temperature.....	-44°F to 90°F (-7°C to 32°C)
the control range of temperature.....	44°F to 90°F (-7°C to 32°C)
Load rating.....	1 amp per terminal, 1.5 amp maximum all terminals combined
Display accuracy.....	± 0.5°C
Power source.....	18 to 30 VAC, NEC Class II, 50/60 Hz for hardware (common wire). Battery power from 2 AA Alkaline batteries
Operating ambient.....	41°F to +95°F (-5°C to +35°C)
Operating humidity.....	90% non-condensing maximum
Dimensions of thermostat.....	118mm × 88mm × 30mm

Name: Qunda Technology (Fangzhi) Co., Ltd.
Address: NO.103 Fangzhiqiang meidu xiaohong economy development area, sushou, jingguo, China
Post code: 215128 Website: www.qunda.com



3.Diagram and Description

11 12 13 14 15




Description

Item	Description
1	Down key: in the cooling/heating mode, it is for lowering the setting temperature. When setting the program and changing the system parameter, it is for adjusting the parameter.
2	Up key: in the cooling/heating mode, it is for raising the setting temperature. When setting the program and changing the system parameter, it is for adjusting the parameter.
3	Mode key: first press for cool mode, and second is for heat mode. Press again will turn off the thermostat.
4	Fan mode: in the cooling/heating mode, switch the fan between on and auto.
5	Run key: Press only once, the thermostat operates according to the time programming. After setting the program and changing the system parameter, press the run key to save and exit the setting interface.

- 6 Hold/Set key: Press the HOLD only once, the LCD display "hold" and the thermostat keeps the current mode and setting temperature in the cool/heat mode, press it to keep the setting temperature, and the setting temperature will not change in the setting process. In the cool/heat mode, press and hold the key for 3 seconds to enter the setting interface. When power off, hold the key for 5 seconds to enter the parameter changing interface.
- 7 Clock/Week: Display the current system time and week.
- 8 Hold symbol: when the symbol displayed, the setting temperature will be kept and won't follow the setting program.
- 9 Room temperature: display the current room temperature.
- 10 Setting temperature: display the setting temperature in the cool/heat mode.
- 11 Battery symbol: it means low power when the symbol displayed, so please change the battery in time.
- 12 Cool symbol: the cooling relay start to work when the symbol displayed. The symbol flashing means the cooling relay is in the set-up delay process.
- 13 Heat symbol: the heating relay start to work when the symbol displayed. The symbol flashing means the cool relay is in the set-up delay process.
- 14 System cool: the symbol displayed means it is in the cooling mode.
- 15 System heat: the symbol displayed means it is in the heating mode.
- 16 Fan: display the current mode of the fan.
- 17 Program setting: it shows the system is in the setting process.

4.Wall locations

The thermostat should be installed approximately 4 to 5 feet above the floor. Select an area with average temperature and good air circulation.



Do not install thermostat at following places:

- Close to hot/cold air ducts
- With direct sunlight
- With an outside wall behind the thermostat
- The areas that do not require conditioning
- Where there are dead spots or drafts (in corners or behind doors)
- Where there might be concealed chimneys or pipes

Installation Tip

Pick an installation location that is easy for the user to access. The temperature of the location should be representative of the building.

6.WIRING

Caution: Electrical Hazard
Failure to disconnect the power before beginning to install this product can cause electrical shock or equipment damage.

Warning :
All components of the control system and the thermostat installation must conform to Class II circuits per the NEC Code.

Wiring

1 If you are replacing a thermostat, take notice of the terminal connections on the base. The wires must be connected correctly. Do not connect the wires to the wrong terminals. For example, the green wire must not be connected to the G terminal.

2 Loosen the terminal block screws. Insert wires then tighten terminal block screws.

3 Place nonflammable insulation into wall opening to prevent drafts.

Terminal Designation

C	Common wire from secondary side of cooling system transformer
RH	Transformer power for heating
RC	Transformer power for cooling
G	Fan relay
Y	Compressor relay
W	Heat relay

Wire specifications
Use shielded or non-shielded 18-22 gauge thermostat wire.

Do not install thermostat at following places:

- Close to hot/cold air ducts
- With direct sunlight
- With an outside wall behind the thermostat
- The areas that do not require conditioning
- Where there are dead spots or drafts (in corners or behind doors)
- Where there might be concealed chimneys or pipes

Installation Tip

Pick an installation location that is easy for the user to access. The temperature of the location should be representative of the building.

Caution:
Do not over tighten terminal block screws, as this can damage terminal block, and keep the terminal block and the base correctly or it will cause electrical operation issues.

Max Torque = 6in-lbs

8.Operation

8.1 Operation

1 COOL/HEAT/OFF: press the "COOL/HEAT/OFF" key once to turn on the system. The mode is cool and "C" is displayed. Meanwhile the room temperature, setting temperature, clock will be also displayed. Change to the heat mode by the second pressing and "H" is displayed. Press again to turn off the system. When "off" is displayed.

(2) Setting temperature: when power on, press "▲" or "▼" to set the temperature. Press "▼" to lower the setting temperature, and press "▲" to raise the setting temperature.

(3) Fan mode: When power on, press it to choose the fan on, and press again to change the fan to auto mode.

(4) Run key: When power on, press the key to run the program what has been set. Meanwhile "Run On" is displayed. In the programming mode or changing the system parameter, press "RUN" to exit and save the changed parameter.

(5) Hold key: When power on, press the "Hold" key to keep the setting temperature. It won't run the program and display "Hold". For example: now the setting temperature is 60°F, after pressing the "Hold" the system will lock the setting temperature to be 60°F.

(6) After finished the setting, press the "RUN" to cancel the setting interface and save the parameter. (If there's no any operation within 30 seconds when setting, the system will exit the setting interface and abandon the changed parameter.)

8.2 Programming setting

When power on (in cool/heat mode), hold "SET" for 3 seconds to enter the programming mode.

(1) First is to set the system clock. When the clock area is flashing, press "▲" or "▼" to change the clock. And if you hold "▲" or "▼", the adjustment will be faster.

(2) Press "SET" again to set the week. When the week area is flashing, press "▲" or "▼" to change the week.

(3) Press "SET" again to set the Wake time from Monday to Friday. When the clock area is flashing, press "▲" or "▼" to adjust the temperature.

(4) Press "SET" again to set the Wake temperature from Monday to Friday. When the clock area is flashing, press "▲" or "▼" to adjust the temperature.

(5) Repeat pressing the "SET", then you can set the time and temperature of Leave, Return, Sleep, from Monday to Friday and Saturday, Sunday by turn.

(6) After finished the setting, press the "RUN" to cancel the setting interface and save the parameter. (If there's no any operation within 30 seconds when setting, the system will exit the setting interface and abandon the changed parameter.)

8.4 Restore factory settings

When power off, hold "FAN" key for 8 seconds. Symbol "DEF" displayed in the clock area shows restoring factory setting is successful, and press "RUN" key to exit.

8.5 System parameter setting

When power off, hold "SET" key for 5 seconds to enter the parameter changing interface.

Room temperature area displays each symbol of the parameter, and system clock area displays each parameter of the parameter values. Repeat to press "SET" key to cycling display the each parameter. Press "▲" or "▼" to adjust each parameter. After finished changing, press "RUN" key to exit the setting interface and save the set parameter. (If there's no any operation within 30 seconds when setting, the system will exit the setting interface and abandons the changed parameter.)

Caution:
Electrical Hazard


Failure to disconnect the power before beginning to install this product can cause electrical shock or equipment damage.

Caution:
Equipment damage hazard


Do not operate the cooling system if the outdoor temperature is below 50°F (10°C) to prevent possible compressor damage.

Step 1: Insert the awl into the slot and pry up the front part of the panel to open it.

Step 2: For horizontal mount put one screw left and one screw right.



Typical 1H/1C system: 1 transformer



Typical 1H/1C heat pump system



Typical heat-only system with fan



Typical cool-only system

EXAMPLE:
Heating/Cooling Schedule Plan/Factory default program setting)

Mode	Period	Weekdays (5 day)		Saturday and Sunday	
		Start Time	Temperature	Start Time	Temperature
Heat	Wake	6:00 AM	21°C	6:00 AM	21°C
Heat	Leave	8:00 AM	17°C	8:00 AM	17°C
Heat	Return	6:00 PM	21°C	6:00 PM	21°C
Heat	Sleep	10:00 PM	17°C	10:00 PM	17°C
Cool	Wake	6:00 AM	24°C	6:00 AM	24°C
Cool	Leave	8:00 AM	28°C	8:00 AM	28°C
Cool	Return	6:00 PM	24°C	6:00 PM	24°C
Cool	Sleep	10:00 PM	28°C	10:00 PM	28°C

8.3 System parameter setting

When power off, hold "SET" key for 5 seconds to enter the parameter changing interface. Room temperature area displays each symbol of the parameter, and system clock area displays each parameter of the parameter values. Repeat to press "SET" key to cycling display the each parameter. Press "▲" or "▼" to adjust each parameter. After finished changing, press "RUN" key to exit the setting interface and save the set parameter. (If there's no any operation within 30 seconds when setting, the system will exit the setting interface and abandons the changed parameter.)

Step	Press Buttons	Display/Factory Default	Press or Hold	Default Parameters	Description
01	SET 5 seconds	CC	FA or SL	FA	Select fast cooling or slow cooling.
02	SET	HC	FA or SL	FA	Select fast heating or slow heating.
03	SET	FC	FA or C	C	Select "T" or "C" readout.
04	SET	CP	9 or 5	9	Compressor Lockout delay time (0 = none ; 5 = Minutes).
05	SET	CA	0° to +5°	0	room temperature error correction.
06	SET	HP	1 or 0	0	conventional heat selection mode (0 = heat pump mode ; 1 = heat pump mode).
07	SET	Ob	O or b	O	Select cool/heat change over valve ("b" = heat change over valve ; "O" = cool change over valve).
08	SET	IC	1 or 0	0	present fan control function ("1" = Active ; "0" = Deactivated).
09	SET	E6	E or 6	E	"E"=Electric ; "G"=Gas
10	RUN	RETURNS TO NORMAL OPERATION			

Step 1: Hold "SET" key for 5 seconds to enter the parameter changing interface.

Step 2: Press "▲" or "▼" to select the parameter you want to change.

Step 3: Press "SET" key to enter the setting interface.

Step 4: Press "▲" or "▼" to adjust the value.

Step 5: Press "SET" key to save the setting.

Step 6: Press "RUN" key to exit the setting interface.

Step 7: Press "SET" key for 5 seconds to exit the parameter changing interface.

Step 8: Press "RUN" key to exit the setting interface.

Step 9: Press "SET" key for 5 seconds to exit the parameter changing interface.

Step 10: Press "RUN" key to exit the setting interface.

Step 11: Press "SET" key for 5 seconds to exit the parameter changing interface.

Step 12: Press "RUN" key to exit the setting interface.

Step 13: Press "SET" key for 5 seconds to exit the parameter changing interface.

Step 14: Press "RUN" key to exit the setting interface.

Step 15: Press "SET" key for 5 seconds to exit the parameter changing interface.

Step 16: Press "RUN" key to exit the setting interface.

Step 17: Press "SET" key for 5 seconds to exit the parameter changing interface.

Step 18: Press "RUN" key to exit the setting interface.

Step 19: Press "SET" key for 5 seconds to exit the parameter changing interface.

Step 20: Press "RUN" key to exit the setting interface.

Step 21: Press "SET" key for 5 seconds to exit the parameter changing interface.

Step 22: Press "RUN" key to exit the setting interface.